






**FLOOR RACK  
(EL-FLOORRACK)  
ASSEMBLY INSTRUCTIONS**  
14" W x 27" H x 30.25" D




# PARTS




FRONT  
(1)



MOUNT  
(1)




BACK BRACE  
(1)



SIDE  
(2)

\* All components, parts, and hardware are packed and shipped in one carton.

# HARDWARE




CONFRAMAT  
SCREW  
(8)




1-1/4" SCREW  
(6)

## TOOLS & SAFETY



Power Drill with  
Phillips bit and  
4mm hex bit



4mm Hex Key

**Two or more people are recommended for unpacking, assembly, and moving. Failure to do so may result in failing of the unit.**

**Failure to follow the assembly directions could result in damage or injury.**

**Install in a level and stable location.**

**Assemble display in the area it will occupy. Never attempt to move display after loading.**



# STEP 1

Attach the **MOUNT** to the **FRONT** panel using **(6) #10 x 1-1/4" SCREWS**.

Attach **(2) SIDES** to the **BACK BRACE** and **MOUNT** panel using **(4) CONFIRMATS** on each side.

